

# OPERATING MANUAL

## MRX-SERIES SAFE LEGAULT CS401-CK TIME DELAY LOCK INSTRUCTIONS

### CHECK LIST

Before proceeding, make sure you have all the included parts within the safe.

If you are missing parts or in need of additional parts or keys, Contact

MESA SAFE COMPANY **Customer Care** : **888.381.8514** [Monday thru Friday 7AM - 4PM/PST]

⚠ **IMPORTANT:** You will need the Medeco Key ID Card to order new keys.



### PARTS INCLUDED:

- ▶ 3 Keys
- ▶ 1 Medeco Key ID Card

### INITIATING TIME DELAY FUNCTION

- ➊ Insert the key [any 1 of 3 included] teeth down into lock at the **12 o'clock** position.
  - ▶ See Figure A
- ➋ Turn key clockwise to the **5 o'clock** position. Key will come to a complete stop.
  - ▶ See Figure B
- ➌ Once in that position, turn key back to **12 o'clock** position.
  - ▶ This will initiate the time delay function.
  - ▶ You may remove key from lock.

### OPENING THE SAFE

- ➍ When the time delay function is in progress, you will hear the lock *ticking*.
  - ▶ Your lock has been previously set with a **1 minute** time delay.
- ➎ Once the time delay is complete, there will be a slight *click*. This signals that the **opening period** has begun.
  - ▶ The **opening period** is when you can actually open your safe. You have a **1 minute** opening period.
- ➏ To open the safe, turn the lock knob clockwise to the **1 o'clock** position.
- ➐ While the lock knob is at the **1 o'clock** position, turn the **handle** counter-clockwise to retract the bolts, opening safe.
  - ▶ See Figure C
  - ▶ Once opened, release the lock knob.

⚠ **IMPORTANT:** Always make sure your safe is **locked & secure** before walking away!



